

Client: American Mold Experts  
C/O: Mr Bill Nicoll, cmi  
Re: Scott M.; Pre TestDate of Sampling: 11-19-2019  
Date of Receipt: 11-20-2019  
Date of Report: 11-20-2019**SPORE TRAP REPORT: NON-VIABLE METHODOLOGY**

Location:	A1: Dining Room			A2: Master Bed		
Comments (see below)	None			None		
Lab ID-Version‡:	10943604-1			10943605-1		
Analysis Date:	11/20/2019			11/20/2019		
	raw ct.	% read	spores/m3	raw ct.	% read	spores/m3
Alternaria				1	100	13
Ascospores	1	25	53			
Basidiospores	4	25	210	1	25	53
Chaetomium	1	100	13			
Cladosporium	1	25	53	1	25	53
Curvularia	1	100	13	1	100	13
Myrothecium						
Nigrospora						
Other colorless						
Penicillium/Aspergillus types†	144	25	7,700	105	25	5,600
Pestalotiopsis				1	100	13
Pithomyces				1	100	13
Rusts	1	100	13	2	100	27
Smuts, Periconia, Myxomycetes	1	100	13	4	100	53
Stachybotrys						
Stemphylium						
Torula						
Ulocladium						
Zygomycetes						
Background debris (1-4+)††	3+			3+		
Hyphal fragments/m3	67			27		
Pollen/m3	< 13			< 13		
Skin cells (1-4+)	1+			2+		
Sample volume (liters)	75			75		
<b>§ TOTAL SPORES/m3</b>			<b>8,100</b>			<b>5,800</b>

**Comments:**

Spore types listed without a count or data entry were not detected during the course of the analysis for the respective sample, indicating a raw count of <1 spore.

† The spores of *Aspergillus* and *Penicillium* (and others such as *Acremonium*, *Paecilomyces*) are small and round with very few distinguishing characteristics. They cannot be differentiated by non-viable sampling methods. Also, some species with very small spores are easily missed, and may be undercounted.

†† Background debris indicates the amount of non-biological particulate matter present on the trace (dust in the air) and the resulting visibility for the analyst. It is rated from 1+ (low) to 4+ (high). Counts from areas with 4+ background debris should be regarded as minimal counts and may be higher than reported. It is important to account for samples volumes when evaluating dust levels.

The analytical sensitivity is the spores/m<sup>3</sup> divided by the raw count, expressed in spores/m<sup>3</sup>. The limit of detection is the analytical sensitivity (in spores/m<sup>3</sup>) multiplied by the sample volume (in liters) divided by 1000 liters.

For more information regarding analytical sensitivity, please contact QA by calling the laboratory.

‡ A "Version" indicated by -"x" after the Lab ID# with a value greater than 1 indicates a sample with amended data. The revision number is reflected by the value of "x".

§ Total Spores/m<sup>3</sup> has been rounded to two significant figures to reflect analytical precision.